



**FILTER SYSTEMS AUSTRALIA**

# **GT16-14 Leak Detector**

## **Install Manual**

### **Kit Components:**

- 1 x Leak Detector Tray
- 1 x Leak Detector
- 1 x Screw Kit for housing half clamp
- 1 x Screw Kit for Leak detector mounting
- 2 x Expandable Felt Pads
- 1 x Adhesive strip
- 4 x Self Adhesive Tray pads

### **Installation:**

1. Remove the all the items from the packaging and ensure you have everything listed above
2. Install the 4 x Self adhesive feet to the bottom of the leak detector tray
3. Remove the leak detector unit from the box and install the 1 x Adhesive strip underneath the leak detector unit
4. Install the leak detector unit onto the tray and screw it down securely
5. Install your desired system onto the tray and using the provided nuts and screws. Clamp the half moon over the canister housing and screw the clamp tightly to hold the housing in place – you do not need to overtighten the unit
6. Install the assembly into the desired location
7. Cut the appropriate length of tubing and install the inlet from your water source to the inlet of the leak detector unit
8. Cut the appropriate lengths of tubing and install the outlet side from the leak detector unit to the inlet side of the filtration system
9. Connect the outlet of the filtration system to the desired tap/fitting
10. Fit the expandable felt pad by removing it from the plastic, flip up lever and install the pad, flip the lever down to cover the pad. This is the normal position for the system to function. When water is detected the foam pad will expand causing it to flip the lever up and shutting down the incoming water supply

1.



2.



3.



4.



5.

